


FOR EXTERNAL A/C POWER, USE ONLY THE SCHOLZ RESEARCH & DEVELOPMENT REGULATED POWER SUPPLY.

Instructions For Use of the Scholz Research & Development Regulated Power Supply:



- 1** Plug the Regulated Power Supply into a 110 volt wall outlet. Insert the Power Supply's mini plug into the minijack located on the side of the Rockman/Soloist.
- 2** Red LED on Rockman/Soloist will flash when the Regulated Power Supply is in use.
- 3** You do not need to remove the batteries in the Rockman. The Power Supply will automatically bypass them.
- 4 CAUTION:** Do not leave the Regulated Power Supply plugged into the wall socket when not in use to power the Rockman/Soloist.

**SR
&
D**