

LIMITED WARRANTY

Scholz Research and Development, Inc. ("SR&D") takes pride in the fact that all SR&D products do not leave our factory without being quality tested to give you care free use. SR&D warrants your product to be free of manufacturing defects for a period of 90 days from the original date of consumer purchase. If this product should become defective within the warranty period, SR&D will elect to repair or replace it, free of charge.

Should you experience a problem with your product, please send it to our service center as described below.

TO OBTAIN WARRANTY SERVICE:

1. Deliver or ship this product with all transportation and insurance charges prepaid to the SR&D Service Center, 134 New Boston Street, Woburn, Massachusetts 01801. For protection, shipment in the original packaging is preferred.
2. A copy of the dealers original dated bill of sale must be included as proof of purchase
3. For expediency, a letter explaining the problem and any other pertinent information should be included.
4. If you have any questions about service, please call the Service Center at 617-932-0551.

This warranty does not extend to any damage caused by misuse, accident, improper installation, corrosion due to faulty batteries, weather related damages, or use contrary to the instructions with the product.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This warranty is valid only in the United States.


SCHOLZ RESEARCH & DEVELOPMENT, INC.
134 New Boston Street, Woburn, Massachusetts 01801

23-030




ROCKMAN™

Triple Footswitch Console






Plugs Labeled on Cable



The three footswitches are independent of each other. Connect them in any order to any combination of devices. Check your Rockmodule manuals for details of switching features. **Note:** Based on internal wiring, most other manufacturers devices will be "ON" when the RED LED is lit, but some devices may be "ON" when the GREEN LED is lit.

LED INDICATION

GREEN RED



Channel 1 on Normal Vol Effect On

Channel 2 on Rhythm Vol Bypass

Chorus On Mix A Effect On

Delay On Mix B Bypass

Switch Open

Switch Shorted To Ground




LED INDICATOR CIRCUIT

This circuit works independently of the actual footswitching. The LEDs turn on whenever you hit a switch, and will turn off about 30 minutes after the last switch action, to save battery life. To turn on the LEDs without changing switch settings, hit a single switch twice in a row. If your batteries go dead, the footswitches will still work, but without the LED indication. Typical battery life is about 500 hours with the LEDs on.

BATTERY INSERTION


Black Tube

Four "D" Cells



Use Alkaline Batteries for Extended Life and Leakage Protection

Remove Two Screws



Bottom Cover

Check Inside Label for Battery Orientation

The Rockman Single Footswitch with LED indication is also available for all general footswitching needs.